THE PROCESSING UNIT AND THE PROGRAM

	2 ¹⁰	2 ⁹	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
	1024	512	256	128	64	32	16	8	4	2	1
1023	0	1	1	1	1	1	1	1	1	1	1
13								1	1	0	1
27							1	1	0	1	1

In the previous papers computer input and output were described as parts of a four component system. In this paper the activity of the third component, the processing unit, is explained.

Computer processing is undertaken with binary numbers, the simplest of all possible number systems, where counting is done in twos using only the digits 0 and 1. This lack of digits is disadvantageous in that binary representations of decimal numbers are always long and consume valuable memory space—for example, the number 1023 in the decimal system requires 10 digits in the binary. The advantage of the binary system is that the information can be coded on the simplest of all possible switches; transistor switches which can be electronically operated in nanoseconds are used. The normal arithmetic functions can then be undertaken by electronic manipulation of the switches according to rules built into the computer by the manufacturer.

Alphabetical characters can be also represented in the computer by giving each letter a numeric code, and computers are often designed so that the whole typewriter keyboard plus a number of graphics characters can be represented. The graphics characters are used to make computer output more acceptable to users.

Computer memory

The computer has two forms of memory, and in the modern microprocessor they are on the same silicon chip.

Read only memory (ROM) contains information inserted by the manufacturer, which tells the microprocessor how to perform the simplest functions such as adding and subtracting. This area of memory also contains instructions which tell the microprocessor how to interpret the user program. The contents of this memory are usually specific to each manufacturer and are permanent while that chip lasts. The microprocessor can take instructions from this memory (read from the memory), but it cannot store information here (write to memory).

Random access memory (RAM)—The other form of memory, also on chips, is a read-write memory, often termed random access memory. This area of memory, which on a modern microcomputer may comprise about 64 kilobytes and in minis and mainframes many megabytes, holds the user's program and probably some of the data. This is termed volatile memory because when the computer is switched off the information is lost; the information in the read only memory is, however, retained.

The important feature of both memories is that read and write instructions can be executed within nanoseconds—in contrast with the slower access to data held in the auxiliary storage devices, which may take several milliseconds. This difference may not seem very great, but when commercial computer time is charged by the millisecond and a simple operation such as sorting a list of numbers into descending order may require thousands of read-write instructions the time taken becomes important.

The user program

Computer software is the general name given to any form of instructions used by computer. The instructions in the read only memory inserted by the manufacturer are one example and the user program another.

The user program is an ordered series of commands which interact with the built in commands in the read only memory to execute the task. The program has two main features—firstly, the desired actions are translated into computer language, and, secondly, it is made up of many simple operations which may be repeated and used in many combinations.

The computer works using the simplest possible collection of functions—for example, add, subtract, identify zero, and the logical functions and, or, not—and most complex tasks, such as long division, are performed by ordered repetition of these functions. The computer manufacturer combines these simple functions into bigger functional units (take the square root of, take the sine of) which users understand. When long division is required the program directs the manufacturer's software in the read only memory to implement the sequence of simple functions.

The programmer uses a programming language to instruct the computer; he could use ordinary English, but the computer would then need a massive built in vocabulary to be able to interpret all the possible linguistic forms. In practice a computer language uses a restricted set of words—usually up to 30. Because computers may be used for many different tasks several programming languages have been developed. Each language is conceptually the same in that it calls up a series of simple functions, but they may be very different in the words they use and the facilities they offer. Some languages are easy to use as the programs read almost like English—for example, Basic and Pascal—and they are termed high level languages. Some high level languages are designed especially for mathematical use—for example, Fortran and Algol—and have enhanced mathematical facilities, whereas others are designed for business use, such as Cobol, which has excellent facilities for accounting. Basic, the Beginners All Symbolic Instruction Code, is a modern language which, though having many disadvantages, is provided with many microcomputers and therefore seems destined to become universal.

The user program can be run in two different ways. In batch processing the user program is submitted to the computer, which holds it along with many others in its memory. When the computer has all the relevant facilities ready—for example, data held on magnetic tapes—the program is run. This method is efficient in computer time and memory use but is slow when the programmer is trying to develop and correct a program, as he might have to wait some time to see the results of his work. This method is often used for running fully developed Fortran programs that need no alteration—for example, the routine calculation of monthly statistics for a practice report. Batch processing is usually confined to the larger minis and mainframes.

Interactive processing is completely under the control of the user. The program is loaded and executed line by line and the user can see the results as they are produced. The computer may be programmed to request data and the user may enter data accordingly; the program may check the entered data. This method of processing is slower than batch processing; it is universally used in microcomputers and is increasingly becoming available on minis and mainframes. A modern mini may be able to handle up to 30 users all apparently running their programs simultaneously, but in reality the computer just does a small bit of each user's program, and then moves round to the next. A hospital based interactive system could have many data input points with visual display units—for example, biochemical results could be directly entered on the computer in the laboratory and reviewed within seconds by the doctor on the ward using a visual display unit; meanwhile the patient's admission record could be being typed on to the computer by a clerk in an adjacent office.

The main attraction of interactive computing for the programmer is that programs can be developed very rapidly. The user, on the other hand, finds the rapid provision of results helpful.

Dr A J Asbury, FFARCS, PHD, is lecturer in anaesthetics, University of Sheffield.